

# Download Eclipse Mp3 T180 Manual

Page 1 Personal Media Player! To get the most out of your purchase, please take the time to carefully read through this manual. Foreword If any problems occur while using your Eclipse, please feel free to contact Mach Speed technical support at 580-272-0035, or send an email to [mssupport@machspeed.com](mailto:mssupport@machspeed.com). Page 2 Precautions • If you do not use your Eclipse for over 24 hours, please switch it to OFF. • Avoid using your Eclipse under extremely hot, cold, dusty or wet environments. Page 3 prompt. Where there is no response when pressing keys and the battery icon displays The player turns off automatically. Connectors pin-out. It appears that you are using AdBlocking software. The cost of running this website is covered by advertisements. It appears that you are using AdBlocking software. The cost of running this website is covered by advertisements. If you like it please feel free to a small amount of money to secure the future of this website.