

# Download Shimano Nexus 8 Speed Hub Service Manual

The Shimano Nexus 8-speed Hub Service Manual. HTML by Sheldon "Totally Enclosed" Brown. The table of contents below is a clickable image map: Note: click right side of detail pages for "next", left side for "previous." • The internal geared hub is not completely waterproof. Avoid using the hub in places where water might get inside and do not use high-pressure water to clean the hub, otherwise the internal mechanism may rust. • Do not disassemble the hub. If you need to disassemble it, contact the place of purchase. Right hand dust cap (Y-34R 98110) GREASE (Y-041 20600) This completes assembly of the Inter-8 hub. 16 Cassette Joint CJ-8S20 for 8 speed CJ-NX10 for 7 speed CJ-8S40 for 8 speed CJ-7S40 for 7 speed CJ-8S20 CJ-NX10 Measurement Tool 101mm TL-CJ10 for CJ-8S20 101mm TL-CJ40 for CJ-8S20 124mm TL-CJ40 for CJ-8S40 17 Spare parts list SHIMANO NEXUS 8 ...- Previous Index Next -> ... <- Previous Index Next ->